



0845 505

7070

Compliance of relevant Health and Safety and Environmental acts is the responsibility of the hirer

SafeHire

at all times .



These guidance notes are provided to the hirer as a reminder of their responsibility towards the operator and third parties and are not intended to be a comprehensive list of safety requirements. Reference should always be made to the manufacturer's operating instructions for further information. CP Hire (GB) Limited accepts no liability for any loss, damage or omission arising from the operation of this item of plant

SAFETY LEAFLET FOR TELEHANDLERS

IT IS IMPORTANT TO READ THIS LEAFLET BEFORE OPERATING THIS MACHINERY

At CP Hire we value our customers and therefore provide this information to ensure the safety of all operators and to outline the effective maintenance and reliability checks necessary to ensure trouble free plant operation. It is essential that this guidance is read and understood by the Hirer before attempting to operate any plant or machinery items. It is general duty of the hirer under current health and safety legislation to provide adequate training and instruction to all employees and this information is intended to supplement that requirement. If at any time you require further information regarding any plant item please do not hesitate to contact your nearest CP Hire Branch.



General Precautions

You must be fully trained and instructed to of plant and equipment.

Ensure that all controls are in "neutral" position before starting engine. Ensure that proper ventilation exists when operating in buildings or areas that may become hazardous due to exhaust fumes etc.

Always wear adequate personal protection equipment (e.g. ear protection, gloves, high visibility coat, hard hat, foot protection, eye protection etc).

Report any defects immediately to your supervisor or the local CP Hire Branch. Where Applicable:

Any plant operated on the public highway may operate plant and equipment. You must have all be subject to the provisions of the Road Traffic information necessary to ensure safe operation Act and therefore, appropriate insurance must be obtained by the Hirer.

> The Hirer is responsible to take all reasonable precautions to prevent theft of any plant or equipment. Such measures should include the removal of any keys when not in use and the provision of a secure area for storage when not in use (e.g. evenings and weekends).

Hirers are responsible for insuring against any loss or damage to the equipment that may occur during the hire period.

Use of mobile phone is prohibited whilst operating this equipment

DAILY MAINTENANCE

Before Starting Work:

Check general condition of machine	Check for any fluid leaks etc.
Check tyres and pressures.	Check fuel level.
Check brakes	Check general operating ability.
Check wheel nuts.	Check lights, including beacon
Check all safety devices and guards.	Check oil and coolant levels, grease where necessary.



SAFETY & MAINTENANCE - TELEHANDLER

It is the hirer's responsibility to ensure that any person operating the telehandler is properly trained, that they are in possession of the apropriate licence to operate the machine, and have all relevant information available.

Please take note and act upon any caution or warning notices that are placed upon the equipment, these could involve maintenance to ensure the effective working of the machinery

Always use the grab handles and steps to get in & out of the telehandler. Keep footplates, pedals and steps clean and free from obstruction & debris.

Always inspect the telehandler prior to use and look for obvious defects (e.g. deflating tyres fork damage etc); never attempt to start/operate the telehandler unless siting in the operator seat. Ensure seat belt is secure.

Rated lifting capacities shown are applicable with the telehandler on a firm, level surface with undamaged, properly inflated tyres. Never attempt to lift a load that is too heavy for the telehandler.

If the automatic safe load indicators are activated this means that the safe working load of the telehandler has been exceeded.

When traveling up or down a slope, ensure that the boom is facing uphill. Avoid traveling across slopes. Exercise extreme caution if operating on a gradient. Always use stabilisers (where necessary)

Avoid violent braking and sudden changes in direction. Be particularly careful when operating where there are pedestrians present, always look behind before reversing. Beware of overhead obstruction. Never allow access beneath the load.

Never carry passengers or use the telehandler for any other purpose than that which it is intended.

Always ensure that the telehandler is secure when not in use, the key is removed, and the door locked (where applicable) Do not use the telehander to tow vehicles/equipment.

Never leave the telehandler unattended with the engine running. Do not allow unauthorised persons to operate the telehandler

Ensure that the ground conditions for operation of any equipment is suitable and fit for purpose. Compliance of the Road Traffic Act is at all times the responsibility of the hirer. It is the hirer's responsibility to make available the equipment for routine servicing.

SAFETY & MAINTENANCE - ATTACHMENT

The attachment must never be used to lift more than the safe working load, always ensure the combined weight of the attachment and load do not exceed the machine safe working load.

Never over extend the boom on telescopic handlers fitted with attachments (refer to the manufacturer information for reference)

Always lift loads with a smooth and even movement, avoid jerking the load and sudden changes in direction

Attachments should always be appropriate for the machine and fitted in a secure manner

Whilst using attachments, never walk or allow any person to walk underneath hoisted loads, always guard against loose items by using appropriate safety equipment. Never put any parts of the body under the load.

It is the hirer's responsibility to make the equipment available for routine servicing