

CP Hire

0808 281

3322

Compliance of relevant Health and Safety and Environmental acts is the responsibility of the hirer at all times .



These guidance notes are provided to the hirer as a reminder of their responsibility towards the operator and third parties and are not intended to be a comprehensive list of safety requirements. Reference should always be made to the manufacturer's operating instructions for further information. CP Hire GBNI Ltd accepts no liability for any loss, damage or omission arising from the operation of this item of plant

SAFETY LEAFLET FOR PRESSURE WASHER BOWSERS


CP Hire 

IT IS IMPORTANT TO READ THIS LEAFLET BEFORE OPERATING THIS MACHINERY

At CP Hire we value our customers and therefore provide this information to ensure the safety of all operators and to outline the effective maintenance and reliability checks necessary to ensure trouble free plant operation. It is essential that this guidance is read and understood by the Hirer before attempting to operate any plant or machinery items . It is general duty of the hirer under current health and safety legislation to provide adequate training and instruction to all employees and this information is intended to supplement that requirement. If at any time you require further information regarding any plant item please do not hesitate to contact your nearest CP Hire Branch.



Protective equipment must be worn when operating this machine



General Precautions

You must be fully trained and instructed to operate plant and equipment. You must have all information necessary to ensure safe operation of plant and equipment.

Ensure that all controls are in "neutral" position before starting engine. Ensure that proper ventilation exists when operating in buildings or areas that may become hazardous due to exhaust fumes etc.

Always wear adequate personal protection equipment (e.g. ear protection, gloves, high visibility coat, hard hat, foot protection, eye protection etc).

Report any defects immediately to your supervisor or the local CP Hire Branch.

Where Applicable:

Any plant operated on the public highway may be subject to the provisions of the Road Traffic Act and therefore, appropriate insurance must be obtained by the Hirer.

The Hirer is responsible to take all reasonable precautions to prevent theft of any plant or equipment. Such measures should include the removal of any keys when not in use and the provision of a secure area for storage when not in use (e.g. evenings and weekends) .

Hirers are responsible for insuring against any loss or damage to the equipment that may occur during the hire period.

Use of mobile phone is prohibited whilst operating this equipment

DAILY MAINTENANCE

Before Starting Work:

- | | |
|--|-----------------------------------|
| Check general condition of machine | Check for any fluid leaks |
| Check tyres, pressures, wheel nuts and brakes. | Check fuel & oil level |
| Check Jockey wheel/support stands | Check condition of hose and lance |
| Check all safety devices and guards. | Check general operating ability |
| Check towing frame and breakaway cable | |



SAFETY & MAINTENANCE

It is the hirer's responsibility to ensure that any person operating any plant / equipment are properly trained and are in possession of all relevant information.

Please take note and act upon any caution or warning notices that are placed upon the equipment, these could involve maintenance to ensure the effective working of the machinery

Under no circumstances is the bowser to be used for any fluid other than for which it is intended.

Bowsers fitted with semi rotary hand pumps must be turned off at the tap when not in use to prevent siphoning.

Ensure all support legs are in use when the bowser is unhitched from the towing vehicle and parked ready to use.

Avoid parking the bowser on an incline, however if the site conditions make this unavoidable, ensure both wheels are chocked as well as engaging the handbrake.

Ensure the bowser is positioned on firm solid ground.

When refueling, do not under any circumstances: smoke, inhale fumes, refuel in an unventilated area or with the engine still hot, refuel near naked flame or leave the engine running.

Always operate in a well ventilated area due to exhaust emissions and ensure that there is safe distance between your work area and all electrical equipment.



Never point the lance at any person, high pressure water can cause serious injury. Be aware that the exhaust can get extremely hot, contact can result in burn injury.

Never leave the bowser unattended with the engine running, Always ensure that the bowser is secure when not in use.

Be aware when towing the bowser on the public highway that compliance of the Road Traffic Act is at all times the responsibility of the hirer.

Bowsers **MUST** be empty at hire termination. Our transport will not collect the bowser if it still contains liquid and an abortive transport charge may be applied.

It is the hirer's responsibility to make available the equipment for routine servicing & safety checks.